

TO-45000 UAZ-SGR

Repair instructions number
00504

Repair instructions name
TO-45000 UAZ-SGR


Applies to
UAZ 220695000046204
...

Model
BUS


Production period
all

Modification
Not selected


Special tools



Hub wrench
315100390114310




Wrench for holding the water pump shaft
005500000404900




Fan viscous clutch removal key
005500000355600


General equipment




Grease gun




Diagnostic system UAZ




A device for measuring the total backlash of the steering




Oil filter remover




Tire pressure gauge



Caliper




Locksmith's beard




Bench hammer



Tool for pressing in cuffs




A device for measuring the density of a coolant (refractometer)



Load fork



Brake bleeder



Universal belt tension tester

Brake pipe wrench



Materials

Sealant-gasket



Refer to the instructions - COMBI - Car installation on lift (C) (00410)

Refer to the instructions - UAZ SANITARY CAR FOR MEDICAL SERVICES, BUS, GLAZED VAN, HATCH, RIGID VEHICLE - Right engine mudguard - Removal / Installation (C) (28011)

Refer to the instructions - UAZ SANITARY CAR FOR MEDICAL SERVICES, BUS, GLAZED VAN, HATCH, RIGID VEHICLE - Left engine mudguard - Removal / Installation (C) (28012)

Refer to the instructions - UAZ SANITARY CAR FOR MEDICAL SERVICES - Radiator grille assembly - Removal / Installation (C) (84001)

1. Work outside the car:

IMAGE



OPERATION DESCRIPTION

1. Check by inspection for chips, cracks and foci of corrosion of the body paintwork.

The presence of chips, cracks and centers of corrosion of the body paintwork is not allowed.

Img 1



2. Check by inspection for chips, cracks on glass and rear-view mirrors, lighting and light signaling devices.



The presence of chips, cracks on glass and rear-view mirrors, lighting and light signaling devices is not allowed.



Img 2




3. Apply grease to the door hinges.



Img 3




4. Apply grease to the front door stops.



Img 4

2. Work inside the car:



Img 1



Img 2

1. Connect the UAZ diagnostic system to the OBD-2 connector.

2. Switch on the ignition.



3. Check for DTCs in the ECM.

4. Check for fault codes in the ABS control unit.

5. Install the parts of the device for measuring the total backlash of the steering on the steering wheel and on the left front wheel of the car.

6. Check the total backlash of the steering according to the operating instructions of the device.


The total backlash should not exceed 20 degrees.



Img 3

7. Lubricate the steering wheel shaft bearing.


Before performing the operation, remove the steering column switches, according to those. card 37074 (C).



Img 4

8. Check the free play of the brake pedal.

The amount of free travel of the brake pedal should be 5-14 mm.




Img 5

9. Check the operation of the seat belt retractor.

The device should wind the belt around the reel easily and without jamming.

10. Check the functionality of the inertia reel of seat belts.


When pulling sharply at different lengths, the inertial coil should block the change in the length of the belt.



Img 6

11. Check the operation of the seat belt locking device.

The belt buckle must fit securely in the device. When unlocking, the buckle must be thrown out of the locking device.




Img 7

12. Warm up the engine to operating temperature.

13. Remove the engine oil filler cap.

3. Work under the car bottom:

IMAGE



Img 1

OPERATION DESCRIPTION

1. Place a container under the oil sump to drain the oil.

2. Unscrew the drain plug on the engine crankcase.

tightening torque- 28 N·m


⚠ NOTIFICATION: Reuse of the O-ring is not permitted.

3. Let the oil drain.

Waiting time is 3-5 minutes.

4. Close the drain plug.

tightening torque- 28 N·m




Img 2

5. Unscrew the oil filter.
tightening torque- 20 N·m

Make sure the filter O-ring is not left on the heat exchanger.


⚠ NOTIFICATION: Filter reuse is not allowed.



Img 3

6. Screw on the filter.


Screw in the filter until the O-ring touches the plane on the heat exchanger, and then turn the filter 3/4 turn.



Img 4

7. Visually inspect the gaskets and seals of the engine, transfer case, steering gear, front and rear axles.

Oil leakage and ejection are not allowed.




Img 5

8. Unscrew the filler plugs of the front and rear axles.

SW=12

tightening torque- 80 N·m



Img 6

9. Unscrew the drain plugs of the front and rear axles.

SW=12

tightening torque- 80 N·m

10. Let the oil drain.

Waiting time is 3-5 minutes.

11. Screw on the drain plugs.

tightening torque- 80 N·m

Apply sealant to the plug threads before installation.



Img 7

12. Unscrew the transmission filler plug.

S=22

tightening torque- 60 N·m



Img 8

13. Remove the transmission drain plug.

S=22

tightening torque- 60 N·m

Clean the plug from wear debris.

14. Let the oil drain.

Waiting time is 3-5 minutes.

15. Close the drain plug.

tightening torque- 60 N·m

Apply sealant to the plug threads before installing.




Img 9

16. Remove the transfer case filler plug.

SW=12

tightening torque- 60 N·m



Img 10

17. Remove the transfer case drain plug.

SW=12

tightening torque- 60 N·m

Clean the plug from wear debris.


18. Let the oil drain.

Waiting time is 3-5 minutes.

19. Close the drain plug.

tightening torque- 60 N·m


Apply sealant to the plug threads before installing.



Img 11

20. Bring the oil level in the front and rear axles to normal.

The oil level should be at the level of the lower edge of the filler hole.




Img 12

21. Screw in the filler plugs of the front and rear axles.

SW=12

tightening torque- 80 N·m


Apply sealant to the plug threads before installation.



Img 13

22. Bring the oil level in the gearbox to normal.

The oil level should be at the level of the lower edge of the filler hole.




23. Screw in the transmission filler plug.

S=22

tightening torque- 60 N·m


Img 14



24. Bring the oil level in the transfer case to normal.

The oil level should be at the level of the lower edge of the filler hole.

Img 15





25. Screw on the filler cap of the transfer case.

SW=12


tightening torque- 60 N·m

Img 16

26. Visually check the connections of the exhaust system for leaks.





Img 17




27. Visually check the connections of the pipelines of the cooling systems, heating, power supply, hydraulic brake drive, vacuum take-off system from the vacuum brake booster, the condition of pipes and hoses.

Leakage of coolant, fuel, brake fluid, leaks in the vacuum hose (vacuum booster) are not allowed. Cracks and ruptures of the hydraulic brake hoses are not allowed. Operation of deformed pipes of the hydraulic drive of brakes, parts of the vacuum take-off system is not allowed.




Img 18



28. Inspect the front suspension springs.

The springs should not have sheet cracks, their longitudinal or transverse displacement.

Img 19




29. Inspect the hinges of the front suspension springs.

The hinges should not have cracks, breaks, undercutting and wear of rubber along the outer end of the hinge.




Img 20




30. Tighten the nuts securing the axle of the front end of the spring.

S=27

tightening torque- 170 N·m




Img 21




31. Tighten the nuts securing the spring shackles.

S=22

tightening torque- 90 N·m




Img 22




32. Tighten the nuts securing the spring ladders.

S=22

tightening torque- 90 N·m




Img 23




Img 24

33. Inspect the front suspension compression bumpers.
Buffers should not have cracks, breaks and deformations.





Img 25

34. Inspect the front suspension shock absorbers.
Oil fogging of the shock absorber does not indicate a malfunction and is acceptable. The appearance of drips on the shock absorber body, indicating a loss of tightness, is not allowed.




35. Inspect the front suspension shock absorber joints.

The hinges should not have cracks, breaks, undercutting and wear of rubber along the outer end of the hinge.



Img 26




Img 27

36. Tighten the front suspension shock absorber retaining nuts.


S=19

tightening torque- 58 N·m




37. Inspect the anti-roll bar joints.

The hinges should not have cracks, breaks, undercutting and wear of rubber along the outer end of the hinge.




Img 28




38. Inspect the anti-roll bar joints.

The hinges should not have cracks, breaks, undercutting and wear of rubber along the outer end of the hinge.




Img 29




39. Tighten the anti-roll bar mounting bolts.

S=17

tightening torque- 50 N·m



Img 30




40. Tighten the nuts securing the anti-roll bar.


S=17

S=19

tightening torque- 58 N·m




Img 31



Img 32



41. Inspect the rear suspension springs.

The springs should not have sheet cracks, their longitudinal or transverse displacement.




42. Inspect the hinges of the rear suspension springs.

The hinges should not have cracks, breaks, undercutting and wear of rubber along the outer end of the hinge.




Img 33




43. Tighten the nuts securing the axle of the front end of the spring.

S=27

tightening torque- 170 N·m




Img 34



44. Tighten the nuts securing the spring shackles.

S=22

tightening torque- 90 N·m




Img 35




45. Tighten the nuts securing the spring ladders.

S=22

tightening torque- 93 N·m




Img 36



46. Inspect the rear suspension compression bumpers.

Buffers should not have cracks, breaks and deformations.


Img 37



47. Inspect the rear suspension shock absorbers.



Oil fogging of the shock absorber does not indicate a malfunction and is acceptable. The appearance of drips on the shock absorber body, indicating a loss of tightness, is not allowed.

Img 38




48. Inspect the rear suspension shock absorber joints.

The hinges should not have cracks, breaks, undercutting and wear of rubber along the outer end of the hinge.



Img 39




49. Tighten the rear suspension shock absorber retaining nuts.


S=17

S=19

tightening torque- 58 N·m



Img 40




Img 41

50. Check the backlash in the crosspieces of the cardan shafts by applying an alternating hand force along the axes of the crosspieces.

Backlash in the crosspieces is not allowed.



51. Rotate the crosspiece 90 degrees and recheck.

Backlash in the crosspieces is not allowed.



Img 42

52. Check the presence of axial play in the bearings of the main gears by moving the drive gear behind the propeller shaft flange.




Img 43

53. Tighten the nuts of the bolts securing the front propeller shaft flanges to the front axle and transfer case flanges.

S=17

S=14

tightening torque- 50 N·m




54. Tighten the nuts and bolts of the rear propeller shaft flanges to the parking brake and rear axle flanges.


S=17

S=14

tightening torque- 50 N·m




Img 44




55. Lubricate the joints of the front and rear propeller shafts.


Lubricate until it comes out from under the working edges of the crosspiece cuffs.




Img 45



56. Lubricate the splines of the front and rear propeller shafts.
Make 3-5 strokes without waiting for the lubricant to come out.



Img 46



57. Check the play in the wheel hub bearings by swinging the wheels in a vertical plane.

No play in the hub bearings is allowed.

Img 47



58. Check the smoothness of rotation of the wheels.

Rolling of the hub bearings and wedging of the wheels during rotation is not allowed.

Img 48




Img 49

59. Inspect the tires of the wheels.

60. Inspect the wheel rims.

61. Check the value of the pressure in the tires of the wheels.


Tire pressures must comply with the values in Table 1.



Img 50

62. Measure the residual depth of the tread pattern.

The residual tread depth must be more than 1.6 mm.




Img 51

63. Check the backlash of the pivots of the steering knuckles.

If there is an axial clearance of the pivots, remove the clearance by tightening the clamping sleeve.

64. Remove the wheels from the vehicle.



Img 52


65. Remove the brake mounting bolts.

S=18

tightening torque- 150 N·m

66. Take the front brake assembly to the side.


Hose tension is not allowed.



Img 53

67. Remove the screws securing the brake disc.
tightening torque- 16 N·m

68. Remove the disc.



Img 54


69. Remove the flange mounting bolts.

S=14

tightening torque- 65 N·m


70. Remove the leading flange together with the gasket.

⚠ NOTIFICATION: Re-use of the spacer is not permitted.




Img 55

71. Bend the tab of the lock washer.




Img 56

72. Unscrew the locknut.
S=55
tightening torque- 25 N·m




Img 57

73. Remove the lock washer.
⚠ NOTIFICATION: Re-use of the washer is not permitted.



Img 58


74. Unscrew the bearing adjustment nut.
S=55
tightening torque- 30 N·m



Img 59

75. Remove the lock washer.

76. Remove the hub.




Img 60

77. Tighten the bolts securing the front axle trunnions.

S=14


tightening torque- 40 N·m



Img 61

78. Remove the cage with the rollers of the outer bearing of the hub.

79. Wash the bearing race.




Img 62

80. Remove the oil seal from the wheel hub.


Tool for pressing in cuffs

⚠ NOTIFICATION: Re-use of the cuff is not permitted.



Img 63


81. Remove the thrust washer of the hub seal.



Img 64

82. Remove the cage with the rollers of the inner bearing of the hub.

83. Wash the bearing race.



Img 65


84. Install the bearing cages with rollers.

85. Install the thrust washer of the hub seal.

86. Install the wheel hub seal.

87. Place a layer of grease 10-15mm thick between the bearings.


⚠ NOTIFICATION: ATTENTION: Do not put more than 200 grams of grease in the hub to avoid it getting into the wheel brakes.



Img 66

88. Install the hub onto the journal.

89. Install the lock washer.




Img 67

90. Screw on the adjusting nut by hand.

S=55

91. Tighten the adjusting nut while turning the wheel by hand.
tightening torque- 140 N·m




Img 68

92. Unscrew the adjusting nut 1/6 - 1/3 turn.

S=55

93. Turn the wheel 1-2 turns.

The wheel should rotate freely without touching the brake pads on the disc or drum.




Img 69

94. Tighten the adjusting nut.

S=55

tightening torque- 30 N·m

When tightening the nut, press the key knob smoothly, without jerks, while turning the wheel to correctly position the rollers on the raceways of the bearing rings.




Img 70

95. Install the lock washer.

96. Tighten the lock nut.


tightening torque- 25 N·m

When properly adjusted, the wheel should rotate freely without binding, noticeable axial play or wobbling.



97. Bend the tabs of the lock washer onto the adjusting nut and locknut.

Img 71



98. Install the leading flange together with the gasket.


99. Tighten the flange mounting bolts.

tightening torque- 10 N·m

100. Finalize the bolts.

tightening torque- 65 N·m

Img 72




101. Install the brake disc.

102. Tighten the screws that secure the brake disc.

tightening torque- 16 N·m

Img 73




Img 74

103. Install the front brake.

104. Tighten the brake mounting bolts.

tightening torque- 150 N·m


105. Perform steps 65 - 104 for the other front wheel hub.



Img 75

106. Remove the screws securing the brake drum.

tightening torque- 16 N·m




Img 76

107. Screw three bolts into the threaded holes of the drum to press out the drum.

Tighten the bolts alternately (by 1/4 turn), avoiding the drum skewing.

108. Press out the drum.




109. Unfasten the rear axle shaft securing bolts.

S=14

tightening torque- 65 N·m

Img 77




110. Screw two bolts into the threaded holes of the half-shaft flange to press out the half-shaft.

S=14

Tighten the bolts alternately (1/4 of a turn), not allowing the axle shaft flange to be skewed.


111. Press out the axle shaft.

Img 78



112. Perform operations 71 - 97 for the rear wheel hubs.


Img 79



Img 80

113. Apply sealant to the inner surface of the hub.

The width of the sealant bead is at least 2 mm, the layer thickness is at least 1 mm. The area where the sealant is applied must be clean and free of grease.



Img 81

114. Install the semiaxis.

When installing, align the splines of the axle shaft with the splines of the differential gear.


115. Wrap the bolts securing the rear axle half shaft.

tightening torque- 10 N·m

116. Complete the final tightening of the bolts.

tightening torque- 65 N·m

117. Install the wheels on the car.




Img 82

118. Tighten the nuts of the body-to-frame bolts.

S=17


tightening torque- 32 N·m



119. Inspect the frame for paint chips, cracks and corrosion centers.


The presence of chips of paintwork, cracks and foci of corrosion of the frame is not allowed.

Img 83



120. Install the bleeding device on the brake master cylinder reservoir.

Img 84



121. Install a hose to the rear right wheel bypass valve.
Place the free end of the hose in a container with brake fluid.

122. Pressurize the brake system by pressing the valve on the bleeder.


123. Unscrew the bypass valve 1/2 - 3/4 turn.
tightening torque- 12 N·m

124. Let the fluid out, screw the valve back on.
tightening torque- 12 N·m

Let the fluid out until the "new" fluid appears from the bypass valve. Remove the rubber hose. The "new" liquid differs from the "old" in a light shade.


125. Repeat the operations for the remaining wheels in the following sequence:

- rear left working brake cylinder; - front right working brake cylinder; - front left working brake cylinder.




Img 85

126. Install the bleeding device on the clutch master cylinder reservoir.



Img 86



Img 87

127. Install the hose to the bypass valve of the clutch slave cylinder.
Place the free end of the hose in a container with brake fluid.

128. Pressurize the clutch system by pressing the bleeder valve.

129. Unscrew the bypass valve 1/2 - 3/4 turn.
tightening torque- 12 N·m


130. Let the fluid out, screw the valve back on.
tightening torque- 12 N·m

Let the fluid out until the "new" fluid appears from the bypass valve. Remove the rubber hose. The "new" liquid differs from the "old" in a light shade.

Lower the car down on a lift.

4. Work in the engine compartment:

IMAGE




Img 1

OPERATION DESCRIPTION

1. Carry out an external inspection of hoses, branch pipes, pipes, engine wires.


If there are traces of contact on the parts of the car, change their position relative to the engine. Scuffs and wear on hoses, branch pipes, pipes, wires are not allowed.



Img 2

2. Visually check the connections of the intake and exhaust systems for leaks.


Leakage of connections is not allowed.



Img 3

3. Check visually the connections of hoses, branch pipes, pipes of the crankcase ventilation system for leaks.

Leakage of connections and damage to hoses are not allowed.



Img 4

4. Check the coolant level in the expansion tank.


Check the coolant level only on a cold engine. The liquid level in the expansion tank should be 3-4 cm above the "min" mark.



Img 5

5. Check the freezing point of the coolant using a refractometer.


The freezing temperature of the coolant should be as follows: - for regions with a temperate climate: $-40-45^{\circ}\text{C}$; - for the regions of the Far North: $-60-65^{\circ}\text{C}$.



Img 6


6. Check the fluid level in the reservoir of the brake master cylinder.

The brake fluid level should be at the "max" mark.




Img 7

7. Check the fluid level in the reservoir of the clutch master cylinder.
The brake fluid level should be 15-20 mm below the top edge of the reservoir.



Img 8

8. Check the tension of the accessory and fan drive belts.
The deflection of the accessory drive belt should be 13-15 mm with a load of 80 N. The deflection of the fan drive belt should be 5-8 mm with a load of 40 N. Damage or excessive stretching of the belts is not allowed.




Img 9

9. Tighten the accessory drive belt tensioner pulley bolt.
S=12
tightening torque- 16 N·m



Img 10

10. Tighten the fan clutch mount.
tightening torque- 55 N·m




Img 11

11. Remove the bolts with washers securing the exhaust manifold shield.

S=12

tightening torque- 16 N·m

12. Remove the exhaust manifold shield.




Img 12

13. Tighten the exhaust manifold retaining nuts.

S=12

tightening torque- 23 N·m



Img 13

14. Fill the engine with oil up to the upper mark on the oil level indicator.


15. Start the engine.

Warm up the engine to operating temperature.

16. Stop the engine.


17. Check the oil level.

Check the oil level after 2 - 3 minutes, after stopping the engine. If necessary, add oil to the upper mark.



Img 14


18. Unscrew the nut with the O-ring of the oil tank cover.



Img 15

19. Remove the oil tank cover with a gasket.

20. Remove the strainer.



21. Loosen the drain hose clamp.


S=7

tightening torque- 5 N·m

22. Disconnect the hose.

23. Drain the oil from the oil tank into a container for draining the oil.

24. Install the hose.



25. Tighten the clamp.

tightening torque- 5 N·m

Img 16

26. Remove the cotter pin from the hairpin.

27. Remove the spring washers.


28. Remove the filter element from the oil tank housing.

29. Install a new filter element in the oil tank.


30. Install washers with a spring.

31. Install the split pin.

Spread the ends of the cotter pin in different directions.



Img 17




Img 18

32. Install the strainer.

Before installation, clean the oil tank strainer from dirt.

33. Pour oil into the hydraulic booster tank.


Fill in oil until it appears above the strainer (no more than 5 mm).



Img 19

34. Turn the steering wheel from lock to lock until air bubbles exit from the oil in the reservoir.


The operation should be performed with the engine off and the front wheels suspended.



Img 20

35. Bleed the power steering system by turning the steering wheel from lock to lock, without holding it in the extreme positions, 3 times in each direction.


The operation should be performed with the engine running and the front wheels suspended. During the operation, add oil to the hydraulic booster tank, preventing its level from dropping below the level of the grid.



Img 21


36. Install the oil tank cover with a gasket.

37. Tighten the nut with the O-ring of the oil tank cover.



38. Clean the leads and wire tips from oxides.

39. Treat leads and wire ends with a means to protect electrical contacts.



Img 22

40. Connect the terminal of the load plug with "plus" to the similar terminal of the battery.


Make the connection without turning on the load coil.

41. Touch the negative pin on the case of the load plug to the negative terminal of the battery.

Record voltmeter readings.

42. Compare the obtained data with the value in Table 2.

If the battery is more than 75% charged, measure under load. If the battery is less than 75% charged, it must be charged.




Img 23

43. Switch on the load coil in the load plug, connect its terminal with "plus" to the same terminal of the battery.

44. Touch the negative pin on the body of the load plug to the negative terminal of the battery, and fix the voltmeter readings at the 5th second.

⚠ NOTIFICATION: DO NOT measure for more than 5 seconds.

45. Compare the obtained data with the value in Table 3 and take the recommended actions.



Img 24

46. Fill in the TO-45000 Card for UAZ-SGR vehicles, Table 4.



Img 25

